

# УСИЛИТЕЛИ

ООО "Алюпласт Украина"  
 Бульвар Независимости 53, 07400 Бровары  
 Тел. +38(044) 331 6924, Факс +38(044) 331 6923  
 info@aluplast.ua | www.aluplast.ua



# УСИЛИТЕЛИ

И	[cm <sup>4</sup> ]				Толщина s [мм]	Артикул	[cm <sup>4</sup> ]				Толщина s [мм]	Артикул	[cm <sup>4</sup> ]				Толщина s [мм]	Артикул	[cm <sup>4</sup> ]				Толщина s [мм]	Артикул																										
	Ix	Iy	Ix	Iy			Ix	Iy	Ix	Iy			Ix	Iy	Ix	Iy			Ix	Iy	Ix	Iy			Ix	Iy																								
для IDEAL 8000 IDEAL 7000 IDEAL 5000 IDEAL 4000 IDEAL 4000 NL IDEAL 2000 Nord-line	для 100075	0.8	1.1		2.0	209075	20.4	0.7		2.0	229018	1.1	0.2		1.5	229045	4.0	5.4		2.0	229120	2.5	0.5		2.0	249004	2.1	0.4		1.2	249037	1.0	2.2		2.0	250101	18.7	9.9		2.0	259926	2.0	1.5		1.5	299944				
	для 100077 TBA	1.2	0.2		2.0	209077	60.6	0.7		2.5	229019	1.4	0.2		1.2	229047	2.1	2.1		1.5	229121	4.7	6.6		2.0	249007	27.1	3.0		1.5	249054	2.1	1.0		2.0	250102	6.6	0.2		1.5	289018	2.0	1.5		1.5	299957				
1) Ix [cm <sup>4</sup> ] -> алюминий x 0,334 = сталь 2) с отверстием	для 100x93	4.8	3.2		1.5	209092	3.7	0.7		2.0	229020	21.5	4.7		2.0	229049	8.5	12.0		2.0	229125	4.5	4.6		2.0	249009	9.0	9.0		~ сталь <sup>1)</sup> алюминий	3.9	1.1		2.0	259002	7.7	2.0		2.0	289066	0.5	0.2		2.0	259006	2.8	2.4		1.5	259010
	для 100095, 100096	6.6	2.2		1.5	209099	8.5	9.6		2.0	229021	4.3	0.2		2.0	229063	12.0	17.0		3.0	229126	1.8	0.6		1.5	249010	3.0	0.3		1.5	249190	0.5	0.2		2.0	259006	3.6	3.1		2.0	259011	7.9	0.4		2.0	259016				
EI угловой соединитель	для 100097, 100098	2.9	0.2		1.5	209121	1.6	0.6		1.0	229025	5.1	4.1		2.0	229073	14.3	14.3		2.0	229135	2.3	0.8		2.0	249011	2.4	0.9		1.5	249192	3.3	0.7		1.25	259015	2.2	5.6		1.5	299220	7.3	0.1		1.5	209000				
	для 140201, 140202, 140267, 180267	7.3	0.1		1.5	209000	2.9	1.1		1.5	229024	4.0	1.4		2.5	229098	14.3	14.3		2.0	229135	7.7	6.9		2.0	249013	5.3	5.0		2.0	249195	3.3	0.7		1.25	259015	3.7	3.7		1.0	299221									
В зависимости от условий монтажа некоторые усилители следует повернуть на 90°.	для 100099	2.1	1.3		1.5	229001	2.3	0.8		1.5	229023	4.0	1.4		2.5	229098	14.3	14.3		2.0	229135	1.8	0.6		1.5	249010	2.4	0.9		1.5	249192	3.3	0.7		1.25	259015	3.7	3.7		1.0	299221									
	для 100099, 100099	2.1	1.3		1.5	229001	2.3	0.8		1.5	229023	4.0	1.4		2.5	229098	14.3	14.3		2.0	229135	1.8	0.6		1.5	249010	2.4	0.9		1.5	249192	3.3	0.7		1.25	259015	3.7	3.7		1.0	299221									
В этом случае необходимо поменять местами значения Ix и Iy:	для 100099, 100099	2.1	1.3		1.5	229001	2.3	0.8		1.5	229023	4.0	1.4		2.5	229098	14.3	14.3		2.0	229135	1.8	0.6		1.5	249010	2.4	0.9		1.5	249192	3.3	0.7		1.25	259015	3.7	3.7		1.0	299221									
	для 100099, 100099	2.1	1.3		1.5	229001	2.3	0.8		1.5	229023	4.0	1.4		2.5	229098	14.3	14.3		2.0	229135	1.8	0.6		1.5	249010	2.4	0.9		1.5	249192	3.3	0.7		1.25	259015	3.7	3.7		1.0	299221									
TBA в стадии разработки (новое или изменено)	для 100099, 100099	2.1	1.3		1.5	229001	2.3	0.8		1.5	229023	4.0	1.4		2.5	229098	14.3	14.3		2.0	229135	1.8	0.6		1.5	249010	2.4	0.9		1.5	249192	3.3	0.7		1.25	259015	3.7	3.7		1.0	299221									
	для 100099, 100099	2.1	1.3		1.5	229001	2.3	0.8		1.5	229023	4.0	1.4		2.5	229098	14.3	14.3		2.0	229135	1.8	0.6		1.5	249010	2.4	0.9		1.5	249192	3.3	0.7		1.25	259015	3.7	3.7		1.0	299221									

Технические изменения или ошибки возможны!